ASSEMBLY INSTRUCTIONS FOR YOUR

OLINDA ACCENT LAMP

ASSEMBLY INSTRUCTIONS:

NOTE: Do not connect the electricity until lamp is fully assembled.

- 1. Unpack all parts, place base (G) on a level surface.
- 2. Remove finial (A) from harp (C).
- 3. Squeeze harp (C) inward and place into the opening of saddle (E).
- 4. Slide center ring of shade spider (located inside shade (B)) over threaded nipple on harp (C).
- 5. Screw finial (A) onto threaded nipple of harp (C) to secure shade to lamp.
- 6. Install one (1) 100W max. Type A, medium base bulb into socket (D).
- 7. Carefully tilt lamp to one side and install one (1) 7W max. Type B, Candelabra base bulb into socket (F). Return lamp to upright position.
- 8. Remove protective plastic (H) from polarized plug (I).
- 9. Insert polarized plug (I) into wall outlet.

Caution: To clean, use a soft cloth only. Do not use any chemical or abrasive cleaners.

Note: Turn the power off (unplug from the wall outlet) before replacing the bulb, making sure the bulb has had sufficient time to cool down. Do not subject the lamp to any shock while lit as shattering of bulb may result.

IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce risk of electric shock, this plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted.

DO NOT ALTER THE PLUG.

